

# **SCREENS**

## **MAINTENANCE TIPS**

Cleaning can be accomplished easily by undoing the fastener away from the screen and lifting the screen away from the window frame. Once removed, spray the screen with a garden hose to remove dust and dirt. Then wash both sides with ammonia and water. Allow to dry.